

X2J52

X2J52

Flip Rack

Front Side

56	X2J52m (Blank panel 1U)
55	
54	X2J52l (AC circuit breaker)
53	
52	
51	X2J52k (Turbine 4U)
50	
49	
48	X2J52j (Heat exchanger 1U)
47	
46	X2J52i - ME Maraton (NOT SPECIFIED)
45	
44	X2J52h (Heat exchanger 1U)
43	X2J52g (ME DC cable distr)
42	
41	
40	
39	
38	
37	
36	
35	
34	X2J52f - Spare RPC LBB 6U (Blank panel 1U)
33	
32	
31	
30	
29	
28	
27	X2J52e - RPC FO Crate 4U (NOT SPECIFIED)
26	
25	
24	
23	
22	
21	
20	
19	X2J52d - Spare RPC EASY 5U (NOT SPECIFIED)
18	
17	
16	
15	
14	
13	
12	
11	
10	
9	
8	
7	X2J52c - RE Link Board Box (Link Board Box)
6	
5	
4	
3	X2J52b (Heat exchanger 1U)
2	X2J52a (Air deflector 2U)
1	

X3J51

## X3J51

Flip Rack

### Front Side

56	X3J51p (Blank panel 1U)
55	X3J51o (AC circuit breaker)
54	
53	
52	X3J51n (Turbine 4U)
51	
50	
49	X3J51m (Heat exchanger 1U)
48	
47	
46	X3J51l - RE EASY 3000 (PL512)
45	
44	
43	
42	
41	X3J51k - RE EASY 3000 (PL512)
40	
39	
38	
37	
36	X3J51j (Heat exchanger 1U)
35	
34	
33	X3J51i - RE AD DC (PL512)
32	
31	X3J51h (DCS PP 1U)
30	X3J51g - PC FO Crate (Fiber Cassette Termination)
29	
28	
27	
26	X3J51f - Spare RPC LBB 6U (Blank panel 1U)
25	
24	
23	
22	
21	X3J51e - RE Link Board Box (Link Board Box)
20	
19	
18	
17	X3J51d - Blank panel 2U (Blank panel 1U)
16	
15	
14	X3J51c - VME+4/6 (NOT SPECIFIED)
13	
12	
11	
10	
9	
8	
7	X3J51b (Heat exchanger 1U)
6	
5	X3J51a (Air deflector 2U)
4	
3	
2	
1	

X4J51

## X4J51

### Flip Rack

#### Front Side

56	X4J51r (Blank panel 1U)
55	X4J51q (AC circuit breaker)
54	
53	
52	X4J51p (Turbine 4U)
51	
50	
49	X4J51o (Heat exchanger 1U)
48	
47	X4J51n (Blank panel 1U)
46	X4J51m - RE Link Board Box (Link Board Box)
45	
44	
43	
42	
41	X4J51l (Blank panel 1U)
40	
39	X4J51k - Spare RPC LBB 6U (Blank panel 1U)
38	
37	
36	
35	X4J51j - Spare ME4/2 HV 30 Crate (Blank panel 6U)
34	
33	
32	
31	
30	X4J51i - ME HV 30 Dist Crate (HV system control PC)
29	
28	
27	
26	X4J51h - ME HV 36 Dist Crate (HV system control PC)
25	
24	
23	
22	
21	X4J51g (Blank panel)
20	
19	
18	X4J51f (ME HV DPP 6U)
17	
16	
15	
14	
13	X4J51e (ME DC cable distr)
12	
11	X4J51d - Spare Heat exchanger 1U (Heat exchanger 1U)
10	
9	X4J51c - SPARE ME4/2 Maraton (HE LV Patch panel)
8	
7	
6	X4J51b (Heat exchanger 1U)
5	
4	X4J51a (Air deflector 2U)
3	
2	
1	

## X2A52

## Flip Rack

## Front Side

56	X2A52p - Blanc panel 1U (CSC Mar DC cable distributor)
55	
54	X2A52o (AC circuit breaker)
53	
52	
51	X2A52n (Turbine 4U)
50	
49	
48	X2A52m (Heat exchanger 1U)
47	
46	X2A52l - ME Maraton (HE LV Patch panel)
45	
44	X2A52k (Heat exchanger 1U)
43	X2A52j (CSC Mar DC cable distributor)
42	
41	
40	X2A52i - RPC Link Board Box (Link Board Box)
39	
38	
37	
36	
35	X2A52h (Blank panel 1U)
34	
33	
32	
31	X2A52g (Blank panel 1U)
30	
29	
28	
27	
26	
25	X2A52f - ME HV 30 Dist Crate (HV system control PC)
24	
23	
22	
21	
20	X2A52e - ME HV 30 Dist Crate (HV system control PC)
19	
18	
17	
16	
15	
14	
13	X2A52d (ME HV DPP 6U)
12	
11	
10	
9	
8	X2A52c - RPC Link Board Box (Link Board Box)
7	
6	
5	
4	
3	X2A52b (Heat exchanger 1U)
2	
1	X2A52a (Air deflector 2U)

# X3A51

## X3A51

### Flip Rack

#### Front Side

56	X3A51p (Blank panel 1U)
55	X3A51o (AC circuit breaker)
54	
53	
52	X3A51n (Turbine 4U)
51	
50	
49	
48	X3A51m - VME+4/3 (NOT SPECIFIED)
47	
46	
45	
44	
43	
42	
41	X3A51l (Heat exchanger 1U)
40	
39	X3A51k (Blank panel 1U)
38	
37	X3A51j - ME FO Crate (Fiber Cassette Termination)
36	
35	
34	X3A51i - Spare RPC LBB 6U (Blank panel 1U)
33	
32	
31	
30	
29	
28	X3A51h (DCS PP 1U)
27	
26	X3A51g - RE EASY 3000 (PL512)
25	
24	
23	
22	
21	X3A51f - RE EASY 3000 (PL512)
20	
19	
18	
17	X3A51e - RE AC DC (PL512)
16	
15	X3A51d - Blank panel 2U (Fan tray 2U)
14	
13	
12	X3A51c (Link Board Box)
11	
10	
9	
8	
7	
6	X3A51b (Heat exchanger 1U)
5	
4	X3A51a (Air deflector 2U)
3	
2	
1	

X4A51

X4A51

Flip Rack

Front Side

56	X4A51q (Blank panel 1U)
55	X4A51p (AC circuit breaker)
54	
53	X4A51o (Turbine 4U)
52	
51	
50	X4A51n - RE Link Board Box (Link Board Box)
49	
48	
47	
46	
45	
44	X4A51m - ME Alignment (DSS)
43	
42	
41	
40	X4A51l (Heat exchanger 1U)
39	
38	X4A51k - Spare RPC LBB 6U (Blank panel 1U)
37	
36	
35	
34	
33	
32	X4A51j - Blank panel 8U (NOT SPECIFIED)
31	
30	
29	
28	
27	
26	
25	
24	X4A51i - DSS-RSS Interface (DSS)
23	
22	
21	
20	X4A51h (Blank panel 3U)
19	
18	X4A51g (ME DC cable distr)
17	
16	X4A51f (Heat exchanger 1U)
15	
14	X4A51e - ME Maraton (NOT SPECIFIED)
13	
12	
11	X4A51d (Heat exchanger 1U)
10	
9	X4A51c - ME Maraton (NOT SPECIFIED)
8	
7	
6	X4A51b (Heat exchanger 1U)
5	
4	X4A51a (Air deflector 2U)
3	
2	
1	

YE-3

X2S52

## X2S52

Flip Rack

### Front Side

56	X2S52p (AC circuit breaker)
55	
54	X2S52o (Turbine 4U)
53	
52	
51	X2S52n (Heat exchanger 1U)
50	
49	X2S52m - SPARE ME4/2 Maraton (HE LV Patch panel)
48	
47	
46	
45	X2S52l (Heat exchanger 1U)
44	X2S52k (ME DC cable distr)
43	X2S52j - Spare RE Link Board Box (Link Board Box)
42	
41	
40	
39	
38	X2S52i - Spare RPC EASY 5U (NOT SPECIFIED)
37	
36	
35	
34	X2S52h - Spare RPC MAO 4U (NOT SPECIFIED)
33	
32	
31	X2S52g - Spare Heat exchanger 1U (Heat exchanger 1U)
30	
29	X2S52f - Spare ME4/2 HV 30 Crate (Blank panel 6U)
28	
27	
26	
25	
24	
23	X2S52e - Spare ME4/2 HV 30 Crate (Blank panel 6U)
22	
21	
20	
19	
18	X2S52d (ME HV DPP 6U)
17	
16	
15	
14	
13	
12	
11	X2S52c - RE Link Board Box (Link Board Box)
10	
9	
8	
7	X2S52b (Heat exchanger 1U)
6	
5	X2S52a (Fan tray 2U)
4	
3	
2	
1	

## X3S51

## Flip Rack

## Front Side

56	X3S51q (AC circuit breaker)
55	
54	X3S51p (Turbine 4U)
53	
52	
51	
50	X3S51o (Heat exchanger 1U)
49	
48	X3S51n - VME-4/3 (NOT SPECIFIED)
47	
46	
45	
44	
43	
42	
41	
40	X3S51m (Blank panel 1U)
39	
38	X3S51l - ME FO Crate (Fiber Cassette Termination)
37	
36	
35	X3S51k (Blank panel 1U)
34	
33	X3S51j - RE EASY 3000 (PL512)
32	
31	
30	
29	
28	
27	X3S51i (Heat exchanger 1U)
26	X3S51h - RE EASY 3000 (PL512)
25	
24	
23	
22	
21	X3S51g (Blank panel 1U)
20	
19	
18	X3S51f - RE AC DC (PL512)
17	X3S51e (Heat exchanger 1U)
16	
15	X3S51d - Spare RPC LBB 6U (Blank panel 1U)
14	
13	
12	
11	
10	
9	X3S51c (Link Board Box)
8	
7	
6	
5	
4	X3S51b (Heat exchanger 1U)
3	
2	X3S51a (Air deflector 2U)
1	



## X4S51

## Flip Rack

## Front Side

56	X4551o (Power distr box)
55	
54	
53	X4551n (Turbine 4U)
52	
51	
50	X4551m (Heat exchanger 1U)
49	
48	
47	X4551l - RE Link Board Box (Link Board Box)
46	
45	
44	
43	
42	
41	X4551k - CSC Alignment DAQ (Alignment DAQ)
40	
39	
38	
37	X4551j - Spare RPC LBB 6U (Blank panel 1U)
36	
35	
34	
33	
32	
31	X4551i (Blank panel 1U)
30	
29	
28	X4551h - DSS-RSS interface YE-3 (NOT SPECIFIED)
27	
26	
25	
24	
23	X4551g (Blank panel 4U)
22	
21	
20	X4551f (Blank panel 6U)
19	
18	
17	
16	
15	
14	X4551e (CSC Mar DC cable distributor)
13	
12	
11	X4551d (Heat exchanger 1U)
10	
9	X4551c - ME Maraton (NOT SPECIFIED)
8	
7	
6	X4551b (Heat exchanger 1U)
5	
4	X4551a (Air deflector 2U)
3	
2	
1	

X2V52

X2V52

Flip Rack

Front Side

56	X2V52n (AC circuit breaker)
55	
54	X2V52m (Turbine 4U)
53	
52	
51	
50	X2V52l (Heat exchanger 1U)
49	
48	X2V52k - ME Maraton (NOT SPECIFIED)
47	
46	
45	X2V52j (Heat exchanger 1U)
44	X2V52i (ME DC cable distr)
43	X2V52h - Blank panel 7U (Blank panel 6U)
42	
41	
40	
39	
38	
37	X2V52g - Spare RPC LBB 6U (Blank panel 1U)
36	
35	
34	
33	
32	
31	X2V52f - RPC FO Crate 4U (NOT SPECIFIED)
30	
29	
28	
27	
26	
25	X2V52e - Spare RPC EASY 6U (NOT SPECIFIED)
24	
23	
22	
21	
20	
19	X2V52d (Blank panel 6U)
18	
17	
16	
15	
14	
13	X2V52c (Link Board Box)
12	
11	
10	
9	
8	
7	X2V52b (Heat exchanger 1U)
6	
5	X2V52a (Air deflector 2U)
4	
3	
2	
1	

# X3V51

## X3V51

Flip Rack

### Front Side

56	X3V51q (AC circuit breaker)
55	
54	X3V51p (Turbine 4U)
53	
52	
51	X3V51o (Heat exchanger 1U)
50	
49	X3V51n - RE EASY 3000 (PL512)
48	
47	
46	
45	
44	
43	X3V51m (Blank panel 1U)
42	
41	X3V51l - RE EASY 3000 (PL512)
40	
39	
38	
37	
36	X3V51k (Blank panel 1U)
35	
34	X3V51j - RE AC DC (PL512)
33	
32	X3V51i (Heat exchanger 1U)
31	
30	X3V51h - Spare RPC LBB 6U (Blank panel 1U)
29	
28	
27	
26	
25	
24	X3V51g (DCS PP 1U)
23	X3V51f (Link Board Box)
22	
21	
20	
19	
18	X3V51e (Blank panel 1U)
17	
16	X3V51d - ME FO Crate (Fiber Cassette Termination)
15	
14	
13	
12	X3V51c - VME-4/6 (NOT SPECIFIED)
11	
10	
9	
8	
7	
6	
5	
4	X3V51b (Heat exchanger 1U)
3	
2	X3V51a (Air deflector 2U)
1	

X4V51

X4V51

Flip Rack

Front Side

56	X4V51p (AC circuit breaker)
55	
54	
53	X4V51o (Turbine 4U)
52	
51	
50	X4V51n (Heat exchanger 1U)
49	
48	X4V51m (Blank panel 1U)
47	X4V51l - RE Link Board Box (Link Board Box)
46	
45	
44	
43	
42	
41	X4V51k (Blank panel 2U)
40	X4V51j - Spare RPC LBB 6U (Blank panel 1U)
39	
38	
37	
36	
35	
34	X4V51i - Spare ME4/2 HV 30 Crate (NOT SPECIFIED)
33	
32	
31	
30	
29	
28	X4V51h - Spare ME4/2 HV 30 Crate (Blank panel 18U)
27	
26	
25	
24	
23	
22	X4V51g - ME HV 36 Dist Crate (HV system control PC)
21	
20	
19	
18	
17	
16	X4V51f (ME HV DPP 6U)
15	
14	
13	
12	
11	
10	X4V51e (ME DC cable distr)
9	
8	X4V51d - Spare Heat exchanger 1U (Heat exchanger 1U)
7	
6	X4V51c - SPARE ME4/2 Maraton (HE LV Patch panel)
5	
4	X4V51b (Heat exchanger 1U)
3	
2	X4V51a (Air deflector 2U)
1	